

MOUNTING CONSIDERATIONS

INSIDE MOUNT

REASONS FOR CHOOSING INSIDE MOUNT

Clean Look

- Inside-mount treatments are installed inside the window casing, showcasing attractive window trim.
- The window trim frames the treatment for a finished, clean appearance.

Allows Sill Space on Deep Windows

- In some deep set windows, the window treatment can be installed to allow plants or other items to be placed on the sill in front of the window treatment.

LIMITATIONS OF INSIDE MOUNT

Light Gaps

- A small deduction in the width and/or length is taken at the manufacturer to allow for proper operating clearance, and this causes a gap on each side of the treatment, affecting the treatment's ability to darken a room.

Obstructed View

- The stack (the compressed state of the window treatment when fully raised) will obstruct part of the view out the window.

Architectural Obstacles

- Obstacles such as handles and cranks can interfere with the operation of inside-mount treatments.

OUTSIDE MOUNT

REASONS FOR CHOOSING OUTSIDE MOUNT

Improve Privacy and Light Control

- Light gaps on the side of the window treatment can be substantially diminished or eliminated.

Fewer Installation Limitations

- Outside-mount window treatments are installed higher than the window opening for an obstructed view when fully raised.
- Outside-mount window treatments are ideal for covering non-square windows.

Architectural Obstacles

- Outside-mount window treatments can clear obstacles like handles and cranks.

Enlarge the Look of a Small Window

- Increase overlap above and below, or to each side of the window.

Hide Window Trim

- Outside-mount treatments can easily hide unattractive window trim

LIMITATIONS OF OUTSIDE MOUNT

Required Surface Above Window Frame

- Outside-mount brackets require at least 2" of flat surface above window or on window frame for mounting brackets. Projection brackets can be ordered if needed to clear frame or moulding.