

MOUNTING CONSIDERATIONS

INSIDE MOUNT

REASONS FOR CHOOSING INSIDE MOUNT

Clean Look

- Inside-mount treatments are installed inside the window casing, showcasing attractive window trim.
- The window trim frames the treatment for a finished, clean appearance.

Allows Sill Space on Deep Windows

- In some deep set windows, the window treatment can be installed to allow plants or other items to be placed on the sill in front of the window treatment.

LIMITATIONS OF INSIDE MOUNT

Light Gaps

- A small deduction in the width and/or length is taken at the manufacturer to allow for proper operating clearance, and this causes a gap on each side of the treatment, affecting the treatment's ability to darken a room.

Obstructed View

- The stack (the compressed state of the window treatment when fully raised) will obstruct part of the view out the window.

Architectural Obstacles

- Obstacles such as handles and cranks can interfere with the operation of inside-mount treatments.

OUTSIDE MOUNT

REASONS FOR CHOOSING OUTSIDE MOUNT

Improve Privacy and Light Control

- Light gaps on the side of the window treatment can be substantially diminished or eliminated.

Fewer Installation Limitations

- Outside-mount window treatments are installed higher than the window opening for an obstructed view when fully raised.
- Outside-mount window treatments are ideal for covering non-square windows.

Architectural Obstacles

- Outside-mount window treatments can clear obstacles like handles and cranks.

Enlarge the Look of a Small Window

- Increase overlap above and below, or to each side of the window.

Hide Window Trim

- Outside-mount treatments can easily hide unattractive window trim

LIMITATIONS OF OUTSIDE MOUNT

Required Surface Above Window Frame


- Outside-mount brackets require at least 2" of flat surface above window or on window frame for mounting brackets. Projection brackets can be ordered if needed to clear frame or moulding.

MEASURING GUIDE FOR HORIZONTAL BLINDS


1" Aluminum & Vinyl Mini-Blinds

Choose Inside or Outside Mount


INSIDE MOUNT - Window Treatments are Installed Inside the Window Casing




Inside Mount Blind



Depth



Width




Height


- 1. Measure Depth:** Determine if window casing has enough depth for an inside-mount window treatment.
- 2. Measure Width:** Measure the inside width of window casing in three places. Record narrowest measurement.
- 3. Measure Height:** Measure the inside height from the top of the window casing to top of the sill in three places. Record the longest measurement.

Note: Do not take any deductions for clearance. The manufacturer will take necessary deductions for a perfect fit.


OUTSIDE MOUNT - Window treatments are mounted directly to wall or moulding




Outside Mount Blind



Width



Headrail Location



Height


- 1. Measure Width:** We recommend 2"- 3" of overlap past the glass or moulding on each side (4"- 6" total) for optimum light control and privacy.
- 2. Determine Headrail location:** Determine if headrail will be on moulding or above moulding. Mark the spot where the top of the headrail will be.
- 3. Measure Height:** Measure from the top of the headrail location to top of sill or lower if overlap is desired for additional light control and privacy.

Note: The manufacturer makes NO deductions on outside mount installations.

MEASURING GUIDE FOR ROLLER SHADES & SOLAR SHADES

Choose Inside or Outside Mount

INSIDE MOUNT - Window Treatments are Installed Inside the Window Casing




- 1. Measure Depth:** Determine if window casing has enough depth for an inside-mount window treatment.
- 2. Measure Width:** Measure the inside width of window casing in three places. Record narrowest measurement.
- 3. Measure Height:** Measure the inside height from the top of the window casing to top of the sill in three places. Record the longest measurement.

Note: Do not take any deductions for clearance. The manufacturer will take necessary deductions for a perfect fit. Measure each window individually as size variances are common.


Light Gaps: On continuous loop and motorized inside mounts, there is approximately 11/16" light gap per side. On cordless inside mounts, there is approximately 9/16" of light gap per side. For optimal light and glare control, outside mount is recommended, or you may add a secondary soft window treatment (drapery or curtain) to hide the light gap on an inside mount.

OUTSIDE MOUNT - Window treatments are mounted directly to wall or moulding




- 1. Measure Width:** We recommend 2"- 3" of overlap past the glass or moulding on each side (4"- 6" total) for optimum light control and privacy.
- 2. Determine Roller location:** Determine if roller will be on moulding or above moulding. (See "Depth Requirements" sheet.) Mark the spot where the top of the moulding will be.
- 3. Measure Height:** Measure from the top of the moulding location to top of sill or lower if overlap is desired for additional light control and privacy.

Note: The manufacturer makes NO deductions on outside mount installations.




DEPTH REQUIREMENTS FOR BLINDS



Blind Type	Headrail Dimensions	Minimum Depth Mount	Flush with Casing	Flush Mount with Valance
1/2" Micro Supreme	1" x 1-1/2"	3/4"	1-3/4"	N/A
1" Classics	1" x 1-1/2"	3/4"	2-1/2"	2-1/2"
1" Insignia	1" x 1"	3/4"	1-5/16"	1-3/4"
1" Supreme	1" x 1-1/2"	3/4"	1-3/4"	N/A
2" Grandeur	1-5/8" x 2-1/4"	3/4"	2-3/8"	3-1/8"

DEPTH REQUIREMENTS FOR SHADES



Roller & Solar Shades	Control Type	Depth Needed for Flush Mount	Depth Needed Partially Recessed
No Valance	Continuous Loop/Motorized	4-1/8"	3/4"
	Cordless	2-1/2"	2"
Small Cassette Valance	Continuous Loop	3-5/8"	1-3/8"
	Cordless	3-1/2"	1-1/2"
Large Cassette Valance	Continuous Loop/Motorized	5-1/2"	1-3/4"
Square Corner Valance	Continuous Loop/Motorized	3/4"	1-3/8"
	Cordless		

MEASURING & ORDERING WORKSHEET

Window # _____ (Location)

Measuring

For Inside Mount

Depth of Window Casing: _____

Measure WIDTH of window in 3 places, and circle the narrowest width below

Width #1 _____

Width #2 _____

Width #3 _____

Measure HEIGHT of window in 3 places, and circle the tallest height below

Height #1 _____

Height #2 _____

Height #3 _____

For Outside Mount

Width _____

Height _____

Ordering

Mount Type: Inside Outside

Ordering Width: _____

Ordering Height: _____

Type of Blind or Shade: _____

Style Name: _____

Color Number: _____

Controls & Options to Consider:

Continuous Loop

Corded

Cordless

Cornice: _____

Valance: _____

Fascia: _____

Window # _____ (Location)

Measuring

For Inside Mount

Depth of Window Casing: _____

Measure WIDTH of window in 3 places, and circle the narrowest width below

Width #1 _____

Width #2 _____

Width #3 _____

Measure HEIGHT of window in 3 places, and circle the tallest height below

Height #1 _____

Height #2 _____

Height #3 _____

For Outside Mount

Width _____

Height _____

Ordering

Mount Type: Inside Outside

Ordering Width: _____

Ordering Height: _____

Type of Blind or Shade: _____

Style Name: _____

Color Number: _____

Controls & Options to Consider:

Continuous Loop

Corded

Cordless

Cornice: _____

Valance: _____

Fascia: _____

Window # _____ (Location)

Measuring

For Inside Mount

Depth of Window Casing: _____

Measure WIDTH of window in 3 places, and circle the narrowest width below

Width #1 _____

Width #2 _____

Width #3 _____

Measure HEIGHT of window in 3 places, and circle the tallest height below

Height #1 _____

Height #2 _____

Height #3 _____

For Outside Mount

Width _____

Height _____

Ordering

Mount Type: Inside Outside

Ordering Width: _____

Ordering Height: _____

Type of Blind or Shade: _____

Style Name: _____

Color Number: _____

Controls & Options to Consider:

Continuous Loop

Corded

Cordless

Cornice: _____

Valance: _____

Fascia: _____